



## Router Login & Network Settings Guide

### How to Log In and Change Your Router Settings

- Open Your Browser: Type 192.168.2.1/#/home or 192.168.1.1/#/home in the address bar.
- Log In to the Router: Username: admin | Password: Wireless password printed on your router.
- Access Settings: Navigate to Settings > SSID and Password.
- Change Network Name and Password: Update SSID and set a new password. Click Save/Apply.
- Reconnect Devices: Use the new network name and password to reconnect all devices.

### Troubleshooting Tips

- Can't Access Login Page? Ensure your device is connected to the router. Try both IP addresses and restart router/browser.
- Forgot Wireless Password? Check the label on your router or reset to factory settings.
- Login Fails? Confirm username is 'admin' and use the correct wireless password.
- Changes Not Saving? Click Save/Apply after updates and restart the router if needed.

Tip: Keep your new password secure. Need help? Contact your ISP or router manufacturer.